

R180 Assembly Guide



What's Required:

- 1-Port R180 VNA
- Phillips Head Screwdriver

STEP 1

Screw the USB bottom enclosure to the 1-Port VNA housing by the M2x5 din 965 screws (4 pcs).

STEP 2

Plug the connector of the USB cable and power supply jack into the appropriate female connectors of the 1-Port VNA.

STEP 3

Insert the top enclosure to the USB bottom enclosure and screw it into the M2.5x12 din 965 screw (1 pc).

Index	Description	Qty
1	USB Bottom Enclosure	1
2	M2x5 din 965 Screw	4
3	Power supply jack	1
4	USB type C connector	1
5	USB Top Enclosure	1
6	M2.5x12 din 965 Screw	1

